



GEL-2060

Interface Range Command

Table of Contents

Chapter 1	Interface Range Command.....	1
1.1	Interface Range.....	1

Chapter 1 Interface Range Command

1.1 Interface Range

Description

interface range *type slot* / <port1 - port2 | port3> [<port1 - port2|port3>]

Parameter

Name	Description	Description
<i>type</i>	Interface type	All legal interface types except for the management interface on the main control board of the rack-mounted switch.
<i>slot</i>	Slot number	All legal slot numbers
<i>port1</i>	Beginning value of the port number	All legal port numbers on the slot.
<i>port2</i>	Ending value of the port number	All legal port numbers on the slot except for port 1.
<i>port3</i>	A single port.	All legal port numbers on the slot.

Default

none

Instruction

Use this command to enter the interface range mode.

Example

Use the following command to enter the interface configuration mode, including slot 0 and fast Ethernet port 1,2,3,6,8,10,11,12:

```
switch_config#interface range 1 - 3 , 6 , 8 , 10 - 12
switch_config_if_range#
```