




1. Take out KVM-0831/KVM-1631



2. Unscrew four screws at the top cover



3. Unscrew two screws on the right side panel




4. Take off the top cover and you should see a screw as shown in the above picture.




5. Unscrew the screw.




6. Replace the top cover.




7. Unscrew the module slot cover at the back.




8. There is a slot inside.



9. Take the slot module, i.e. ACC-1000.




10. Slowly insert the module into the slot.



11. Be careful not to bend or damage capacitors while inserting.



12. When correctly inserted, there is a screw hole at the upper left hand corner.



13. Fixed the module with a screw.



14. Finish the module installation.