



GEL-2060

MLD-Snooping Configuration Commands

Table of Contents

Chapter 1 MLD Multicast Configuration Commands	1
1.1 ipv6 mld-snooping {enable disable}.....	1
1.2 ipv6 mld-snooping solicitation	2
1.3 ipv6 mld-snooping vlan <i>vlan_id</i> static <i>X:X:X:X</i> interface <i>intf</i>	3
1.4 ipv6 mld-snooping timer router-age <i>timer_value</i>	3
1.5 ipv6 mld-snooping timer response-time <i>timer_value</i>	4
1.6 ipv6 mld-snooping vlan <i>vlan_id</i> mrouter interface <i>intf_name</i>	5
1.7 ipv6 mld-snooping vlan <i>vlan_id</i> immediate-leave	5
1.8 show ipv6 mld-snooping	6
1.9 show ipv6 mld-snooping timer	7
1.10 show ipv6 mld-snooping groups	8
1.11 show ipv6 mld-snooping statistics	9
1.12 show ipv6 mld-snooping mac	10

Chapter 1 MLD Multicast Configuration Commands

The MLD multicast configuration commands include:

- **ipv6 mld-snooping**
- **ipv6 mld-snooping solicitation**
- **ipv6 mld-snooping vlan *vlan_id* static *X:X:X:X::X* interface *intf***
- **ipv6 mld-snooping timer router-age *timer_value***
- **ipv6 mld-snooping timer response-time *timer_value***
- **ipv6 mld-snooping vlan *vlan_id* mrouter interface *intf_name***
- **ipv6 mld-snooping vlan *vlan_id* immediate-leave**
- **show ipv6 mld-snooping**
- **show ipv6 mld-snooping timer**
- **show ipv6 mld-snooping groups**
- **show ipv6 mld-snooping statistics**
- **show ipv6 mld-snooping mac**

1.1 ipv6 mld-snooping {enable | disable}

Syntax

ipv6 mld-snooping

no ipv6 mld-snooping

To enable MLD snooping, run **ipv6 mld-snooping**.

Parameter

None

Default value

This command is used to enable MLD snooping.

Remarks

After MLD snooping is enabled, when DLF occurs on multicast packets (that is, the destination address is not registered in the swap chip through the MLD-snooping), all multicast packets whose destination addresses are not registered on any port will be dropped.

Example

The following example shows how to enable the MLD snooping function:

```
switch_config# ipv6 mld-snooping
```

1.2 ipv6 mld-snooping solicitation

Syntax

ipv6 mld-snooping solicitation

no ipv6 mld-snooping solicitation

To enable or disable the hardware forwarding of the multicast group, run **ip mld-snooping solicitation**. To resume the default value, run **no ip mld-snooping solicitation**.

Parameter

None

Default value

This function is shut down.

Remarks

None

Example

The following example shows how to enable the hardware forward of the multicast group.

```
switch_config# ipv6 mld-snooping solicitation
```

1.3 ipv6 mld-snooping vlan *vlan_id* static *X:X:X:X::X* interface *intf*

Syntax

ipv6 mld-snooping vlan *vlan_id* static *X:X:X:X::X* interface *intf*

no ipv6 mld-snooping vlan *vlan_id* static *X:X:X:X::X* interface *intf*

Parameter

Parameter	Description
<i>vlan_id</i>	Stands for the ID of a VLAN. Value range: 1-4094
<i>X:X:X:X::X</i>	IP address of the multicast
<i>intf</i>	An interface

Default value

None

Remarks

This command is used to configure the static multicast address of VLAN. Its negative form is used to cancel the static multicast address.

Example

The following example shows how to add the static multicast address, ff12::5, to interface g1/1.

```
switch_config# ipv6 mld-snooping vlan 1 static ff12::5 interface g1/1
switch_config#
```

1.4 ipv6 mld-snooping timer router-age *timer_value*

Syntax

ipv6 mld-snooping timer router-age *timer_value*

no ipv6 mld-snooping timer router-age

Parameter

Parameter	Description
-----------	-------------

<i>time value</i>	Queries the time of the timer. Value range: 10-2147483647
-------------------	---

Default value

260 seconds

Remarks

This command is used to query the time of the timer of MLD-Snooping. The negative form of this command is used to resume the default value.

Example

The following example shows how to set the query time of the router to 300 seconds.

```
switch_config# ipv6 mld-snooping timer router-age 300
switch_config#
```

1.5 ipv6 mld-snooping timer response-time *timer_value*

Syntax

ipv6 mld-snooping timer response-time *timer_value*

no ipv6 mld-snooping timer response-time

To configure the maximum response time of IGMP snooping, run **ip mld-snooping timer response-time** *timer_value*. To resume the default value of IGMP snooping, run **no ip mld-snooping timer response-time** *timer_value*.

Parameter

Parameter	Description
<i>time value</i>	Queries the time of the timer. Value range: 1-255

Default value

15 seconds

Remarks

None

Example

The following example shows how to set the query response time of IGMP snooping to 20 seconds.

```
switch_config# ipv6 mld-snooping timer response-time 20
```

1.6 ipv6 mld-snooping vlan *vlan_id* mrouter interface *inft_name*

Syntax

ipv6 mld-snooping vlan *vlan_id* mrouter interface *inft_name*

no ipv6 mld-snooping vlan *vlan_id* mrouter interface *inft_name*

To set the static multicast router's port of MLD snooping, run the first one of the above-mentioned commands.

Parameter

Parameter	Description
<i>vlan id</i>	Stands for the ID of a VLAN. Value range: 1-4094
<i>X:X:X:X::X</i>	IP address of the multicast
<i>inft_name</i>	Shows the port type, the slot and the port ID.

Default value

15 seconds

Remarks

None

Example

The following example shows how to set interface g1/4 to be the interface of the static multicast router of MLD snooping.

```
switch_config# ipv6 mld-snooping vlan 1 mrouter interface g1/4
```

1.7 ipv6 mld-snooping vlan *vlan_id* immediate-leave

Syntax

ipv6 mld-snooping vlan *vlan_id* immediate-leave

no ipv6 mld-snooping vlan *vlan_id* immediate-leave

Parameter

Parameter	Description
<i>vlan_id</i>	Stands for the ID of a VLAN. Value range: 1-4094

Default value

The immediate-leave functionality is disabled.

Remarks

This command is used to set the immediate-leave functionality.

Example

The following example shows how to enable the immediate-leave functionality on VLAN 1:

```
switch_config# ipv6 mld-snooping vlan 1 immediate-leave
switch_config#
```

1.8 show ipv6 mld-snooping

Syntax

show ipv6 mld-snooping

Parameter

None

Default value

None

Remarks

This command is used to display the information about MLD-snooping configuration.

Example

The following example shows how to display the information about MLD snooping.


```
switch#show ipv6 mld-snooping
```

```
Global MLD snooping configuration:
```

```
-----
Globally enable      : Enabled
Querier              : Enabled
Querier address      : FE80::3FF:FEFE:FD00:1
Router age           : 260 s
Response time        : 10 s
Handle Solicitation  : Enabled
```

```
Vlan 1:
```

```
-----
Running
Routers: SWITCH(querier);
```

```
Vlan 2:
```

```
-----
Running
Routers: SWITCH(querier);
```

```
Switch_config#show ipv6 mld-s g
```

```
Vlan Group          Type Port(s)
```

```
-----
1 FF02::1:FF13:647D MLD  G1/23
1 FF02::1:FF13:394 MLD  G1/23
2 FF02::1:FF00:2 MLD    G1/22
1 FF02::1:FF00:12 MLD   G1/23
1 FF02::1:FF00:2 MLD    G1/23
2 FF02::1:FF61:9901 MLD  G1/22
```

```
switch#
```

1.9 show ipv6 mld-snooping timer

Syntax

```
show ipv6 mld-snooping timer
```

Parameter

None

Default value

None

Remarks

This command is used to display the information about the MLD-snooping clock.

Example

The following example shows how to display the information about the MLD-snooping clock.

```
switch#show ipv6 mld-snooping timers
```

```
vlan 1 Querier on port 0 : 251
```

```
vlan 2 Querier on port 0 : 251
```

```
vlan 2 multicast address 3333.0000.0005 response time : 13
```

```
switch#
```

vlan 2 multicast address 3333.0000.0005 response time : This shows the time period from receiving a multicast query packet to the present; if there is no host to respond when the timer times out, the port will be canceled.

1.10 show ipv6 mld-snooping groups

Syntax

```
show ipv6 mld-snooping groups
```

Parameter

None

Default value

None

Remarks

This command is used to display the information about the multicast group of MLD-snooping.

Example

The following example shows how to display the information about the multicast group of MLD-snooping.

```
switch# show ipv6 mld-snooping timer
```

Vlan Group	Type Port(s)
------------	--------------

```
-----  
2 FF02::1:FF00:2 MLD G2/22  
2 FF02::1:FF61:9901 MLD G2/22  
1 FF02::1:FF13:394 MLD G2/23  
1 FF02::1:FF00:2 MLD G2/23  
1 FF02::1:FF00:12 MLD G2/23  
1 FF02::1:FF13:647D MLD G2/23  
switch#
```

1.11 show ipv6 mld-snooping statistics

Syntax

show ipv6 mld-snooping statistics

Parameter

None

Default value

None

Remarks

This command is used to display the information about MLD-snooping statistics.

Example

The following example shows how to display the information about MLD-snooping statistics.

```
switch#show ipv6 mld-snooping statistics  
v1_packets:0      Quantity of MLD v1 packets  
v2_packets:6      Quantity of MLD v2 packets  
v3_packets:0      Quantity of MLD v3 packets  
general_query_packets:5  Quantity of general query packets  
special_query_packets:0  Quantity of special query packets  
listener_packets:6  Quantity of Report packets  
done_packets:0     Quantity of Leave packets  
err_packets:0      Quantity of error packets
```

1.12 show ipv6 mld-snooping mac

Syntax

show ipv6 mld-snooping mac

Parameter

None

Default value

None

Remarks

This command is used to display the multicast MAC of MLD snooping.

Example

The following example shows how to display the multicast MAC of MLD snooping.

```
switch#show ipv6 mld-snooping mac
```

Vlan	Mac	Ref	Flags
1	3333:0000:0001	1	2
2	3333:ff61:9901	1	0
	FF02::1:FF61:9901		
1	3333:0000:0002	1	2
1	3333:ff00:0002	1	0
	FF02::1:FF00:2		
1	3333:ff00:0012	1	0
	FF02::1:FF00:12		
1	3333:ff13:647d	1	0
	FF02::1:FF13:647D		
2	3333:ff00:0002	1	0
	FF02::1:FF00:2		
1	3333:ff13:0394	1	0
	FF02::1:FF13:394		
1	3333:ff00:0001	1	2
1	3333:ff8e:7000	1	2

```
switch#
```

Ref means the quantity of referred IPv6 addresses of MAC.

Flags means the debug output information, and 2 means the information need be sent to CPU.