

Network Camera

Addendum for Playing Recorded Files


When you play an audio/video recording in Windows Media Player, you may not be able to hear the audio if the necessary audio codec is not installed and automatic installation of this audio codec is blocked. In this case, you need to change the ActiveX security setting and then install the audio codec.

1. Change Security Settings :

1. Open Internet Explorer.
2. Click **Tools** and then **Internet Options**.



3. Click the **Security** tab and then the "Custom Level" button.
4. For the *Download unsigned ActiveX controls* setting, select the "Prompt" radio button.



5. Click the **OK** button then click the **Yes** button when Windows asks, "Are you sure you want to change the security settings for this zone?"
6. Click the **OK** button on the *Internet Options* window to save your changes.

2. Install the audio codec :

To install the audio codec and play an audio/video recording, follow these instructions:

1. Click the icon of the recording you want to play.
2. Make sure your PC is connected to the Internet.
3. Windows Media Player will launch. A security warning message will appear, asking you to install this file, sg726acm.cab. Click the **Install** or **Yes** button.



4. After the audio codec has been installed, your audio/video recording will begin playing.

NOTE: We recommend that you return to the [Internet Options - Security Settings](#) window and disable the [Download unsigned ActiveX controls](#) setting.

